



W = 30' Max. for Private Use.

W = 30' Max. for Commercial When Angle at Entrance is  $45^\circ - 60^\circ$

W = 35' Max. for Commercial When Angle at Entrance is  $61^\circ - 90^\circ$

Note: Size and Flowline of Culverts Shall be Adequate for Proper Highway Drainage

Figure 6-15: Private or Commercial Driveway